

Wakeup On LAN Instructions for GX150s & GX240s

1. Turn on Machine
2. Go into BIOS (press F2) at the Dell® startup screen
3. Once in BIOS scroll down to Remote Wakeup option
4. Turn ON by pressing right arrow key
5. Press ALT B to reboot

NOTE: Once the computers are configured for Wakeup On LAN the network devices may also need to be configured to allow "ip directed broadcasts". Please speak to Network for these changes if the wakeup feature is not working.

